






住戸平面図

住宅名

浪速第9



3DK	701	702	703	704	705	706	707	708	709	710	711	712	713	階段
	601							607						
	501							507						
	401							407						
	301							307						
	201							207						
	101	102	103	104	105	106	107	108	109	110	111	112	113	
3DK店														

3DK	701	702	703	704	705	706	707	708	709	710	711	712	713	階段
	601				605	606				610				
	501				505	506				510				
	401				405	406				410				
	301				305	306				310				
	201				205	206				210				
	101	102	103	104	105	106	107	108	109	110	111	112	113	
3DK身														

3DK	601	602	603	604	605	606	607	608	609	610	611	612	613	階段
	501				505	506				510				
	401				405	406				410				
	301				305	306				310				
	201				205	206				210				
	101	102	103	104	105	106	107	108	109	110	111	112	113	
	3DK身													

2号館

3号館