



住戸平面図


住宅名	瓜破東第 1
-----	--------




1 号館 (96206-01) 3DK




1 号館 (96207-01) 3DK-2




1 号館 (96205-01) 2DK




1 号館 (96208-01) 2DK (老)



1 号館 (96210-01) 2DK-2 (身)



1 号館 (96205-02) 2DK (老)



1 号館 (96209-02) 3DK (身)


501	502	503	504	505	506	507	508	509	EV
401								409	
301								309	
201								209	
101	102	103	104	105	106	107	108	109	

1 号 館


住戸平面図

住宅名


瓜破東第 1




2 号館 (92201-01) 3DK



2 号館 (92207-01) 2DK



2 号館 (92208-01) 2DK ②




2 号館 (92209-01) 3DK ②

						1306	1307				
1201	1202	1203	1204	1205	1206	1207		1308	1309	1310	1311
1101						1107		1208			1211
1001						1007		1108			1111
901						907		1008			1011
801						807		908			911
701						707		808			811
601						607		708			711
501						507		608			611
401						407		508			511
301						307		408			411
201						207		308			311
101	102	103	104	105	106	ピロティ		208			211
								108	109	110	111


2 号 館

住戸平面図


住宅名	瓜破東第 1
-----	--------



3, 4 号館 2DK (96161-01)



3, 4 号館 3DK (96162-01)



3, 4 号館 3DK-2 (96163-01)

							EV
601	602	603	604	605	606	607	
501						507	
401						407	
301						307	
201					206	207	
101	102	103	104	105	ピロティ		

3 号 館





EV	601	602	603	604	605	606	607
	501						507
	401						407
	301						307
	201	202					207
	ピロティ		103	104	105	106	107

4 号 館

住戸平面図

住宅名

瓜破東第 1





5 号館 3DK (93151-02)

5 号館 2DK (93150-05)

5 号館 2LDK (老) (93152-03)

5 号館 2DK (老) (93150-06)

<>内は、13階部分を示す。



5 号館 3DK (身) (93154-01)

3DK				2DK	3DK	2DK
1301	1302	1303	1304	1305		
1201			1204	1205		
1101			1104	1105	1106	1107
1001			1004	1005		
901			904	905		
801			804	805		
701			704	705		
601			604	605		
501			504	505		
401			404	405		
301			304	305		
201			204	205		
101	102	103	104	105	106	107
(身)				(老)		

5 号館